

# HARDWARE LIST

Key	Description	Picture	Qty
A	Caster Pin		1
B	1/4"-20UNC×13 Screw		25
C	#8X3/8" Tapping Screw		5
D	NO.10-24UNC×13 Screw		17
E	NO.10-24UNC Nut		1
F	1/4"×18 Screw Assy		2
G	Ø6.5 Al Washer		6
H	Ø5 Lock Washer		4
J	Ø5 Washer		4
K	Hose clip		1
L	1/4"-20UNC Nut		1

# REPLACEMENT PARTS LIST FOR 468502422, 468162422

Key	Qty	Description
1	1	TOP LID
2	1	HANDLE F/ LID
3	2	RUBBER BUMPER, W/ HOLE, F/ TOP LID
4	1	LOGO PLATE F/ LID
5	1	THERMOMETER
6	1	BEZEL, F/ THERMOMETER
7	1	TOP LID HARDWARE
8	1	WARMING RACK
9	2	EMITTER, F/ COOKING GRATE, 120
10	1	EMITTER, F/ COOKING GRATE, 180
11	2	COOKING GRATE, 120
12	1	COOKING GRATE, 180
13	1	FIREBOX
14	2	LID STOP, FIREBOX
15	4	MAIN BURNER
16	4	BURNER BRACE
17	1	ELECTRODE, F/ MAIN BURNER
18	1	ELECTRODE, F/ MAIN BURNER, 500MM WIRE
19	2	ELECTRODE, F/ MAIN BURNER, 600MM WIRE
20	3	CARRY OVER TUBE
21	1	CONTROL PANEL, MAIN
22	1	VALVE ASSEMBLY
23	4	CONTROL KNOB
24	4	BEZEL F/ CONTROL KNOB
25	1	RIGHT SIDE SHELF
26	1	FASCIA, F/ RIGHT SIDE SHELF
27	1	SHELF SUPPORT, RIGHT
28	1	LEFT SIDE SHELF
29	1	FASCIA, F/ LEFT SIDE SHELF
30	1	SHELF SUPPORT, LEFT
31	1	IGNITER SWITCH MODULE
32	1	LEFT SIDE CART PANEL
33	1	RIGHT SIDE CART PANEL
34	1	FRONT DOOR BRACE

Key	Qty	Description
35	2	MAGNET ASSEMBLY
36	2	DOOR PIN, SPRING
37	1	LEFT DOOR, NO HANDLE
38	2	HANDLE, F/ DOOR
39	1	RIGHT DOOR, NO HANDLE
40	1	BOTTOM SHELF
41	2	TANK SUPPORT
42	2	DOOR PIN, FIXED
43	1	REAR CART PANEL
44	1	SHIELD, F/ TANK
45	2	CASTER, LOCKING
46	2	CASTER, FIXED
47	1	MATCH HOLDER
48	1	GREASE TRAY
49	2	GREASE TRAY BRACKET
50	1	GREASE PAN
51	1	ELECTRONIC IGNITION MODULE
52	1	CAP, F/ IGNITION MODULE
53	2	TOOL HOLDER
54	1	TANK STRAP
NOT Pictured		
...	1	PRODUCT GUIDE, EUROPE
...	1	HARDWARE PACK
...	1	CASTER PIN
...	1	EMITTER CLEANING TOOL
...	1	REGULATOR HOSE CLIP (IF REQUIRED)

# REPLACEMENT PARTS DIAGRAM FOR 468502422, 468162422

